

BRICKLITER LAMP REPLACEMENT

TOOLS REQUIRED:

- Phillips screwdriver

1. Carefully remove the 2 main screws with a Phillips screws.
2. Being careful not to scratch the fixture's finish, remove the plate and carefully remove the plexiglass.
3. Inspect the sockets if needed replace them. Replace the lamp by push in and turning counter clockwise.
4. Replace lamps with LO-93 (standard) or review spec on Cutsheet, To replace the lamp push in and turning clockwise.
5. Replace outer plexiglass and the plate (inspect the back of the face to see if the seal tape needs replacing). Make sure the grille is facing downward.
6. Carefully replace the 2 main screws do not over tighten.



1705 E. Colton Avenue
Redlands, CA 92374
(800) 544-4840
www.nightscaping.com

Nightscaping® The Safe System

BRICKLITER LAMP REPLACEMENT

TOOLS REQUIRED:

- Phillips screwdriver

1. Carefully remove the 2 main screws with a Phillips screws.
2. Being careful not to scratch the fixture's finish, remove the plate and carefully remove the plexiglass.
3. Inspect the sockets if needed replace them. Replace the lamp by push in and turning counter clockwise.
4. Replace lamps with LO-93 (standard) or review spec on Cutsheet, To replace the lamp push in and turning clockwise.
5. Replace outer plexiglass and the plate (inspect the back of the face to see if the seal tape needs replacing). Make sure the grille is facing downward.
6. Carefully replace the 2 main screws do not over tighten.



1705 E. Colton Avenue
Redlands, CA 92374
(800) 544-4840
www.nightscaping.com

Nightscaping® The Safe System

BRICKLITER LAMP REPLACEMENT

TOOLS REQUIRED:

- Phillips screwdriver

1. Carefully remove the 2 main screws with a Phillips screws.
2. Being careful not to scratch the fixture's finish, remove the plate and carefully remove the plexiglass.
3. Inspect the sockets if needed replace them. Replace the lamp by push in and turning counter clockwise.
4. Replace lamps with LO-93 (standard) or review spec on Cutsheet, To replace the lamp push in and turning clockwise.
5. Replace outer plexiglass and the plate (inspect the back of the face to see if the seal tape needs replacing). Make sure the grille is facing downward.
6. Carefully replace the 2 main screws do not over tighten.



1705 E. Colton Avenue
Redlands, CA 92374
(800) 544-4840
www.nightscaping.com

Nightscaping® The Safe System

BRICKLITER LAMP REPLACEMENT

TOOLS REQUIRED:

- Phillips screwdriver

1. Carefully remove the 2 main screws with a Phillips screws.
2. Being careful not to scratch the fixture's finish, remove the plate and carefully remove the plexiglass.
3. Inspect the sockets if needed replace them. Replace the lamp by push in and turning counter clockwise.
4. Replace lamps with LO-93 (standard) or review spec on Cutsheet, To replace the lamp push in and turning clockwise.
5. Replace outer plexiglass and the plate (inspect the back of the face to see if the seal tape needs replacing). Make sure the grille is facing downward.
6. Carefully replace the 2 main screws do not over tighten.



1705 E. Colton Avenue
Redlands, CA 92374
(800) 544-4840
www.nightscaping.com

Nightscaping® The Safe System