

To access the lamp on the Exceliter,  
Hold the fixture body (tube) with your right hand, hold the back cap with your left hand, then twist the back cap away from the body like the lid of a jar. It may take a bit of effort, possibly some WD-40 to help loosen the back cap, but it does come apart. Once you have it open, the lamp pulls out the back and can be replaced at that point. Regarding setting your timer...there are instructions on our web site, however, we have several timers. You will need to look through several of the following links to find your timer.