


### Introduction


The X-10 Mini Controller lets you remotely control any Nightscaping® Transformers from anywhere in your home. You can keep it by the bedside and turn off any Powercenter™ without getting out of bed. You can turn on ALL Powercenters™ connected to X-10 modules with the push of a button.

How many times have you gone to bed and left a downstairs light on because you didn't want to get out of bed to turn it off? Now you don't have to.



RC-4000

- ① The "ON" buttons
- ② The "OFF" buttons
- ③ Buttons "1-4" or "5-8"
- ④ Plug into any 120V wall receptacle
- ⑤ House code dial "choose any of the 16 dial and set all your Modules to the same letter"
- ⑥ All "ON" and "OFF", "DIM" and "BRIGHT" buttons don't functions with our Powercenters™
- ⑦ Selector switch "1-4" or "5-8"



### How it works

The Mini Controller tells the Modules what to do. Command signals are sent over your existing house wiring to the Module or Modules of your choice. The Modules respond to the command signals and the Powercenters™ turns on and off.

### Instructions

#### Step #1


Set all your Nightscaping® X-10 modules to the same letter (house code dial) ⑤ and set a button number ③ "1-4" or "5-8" and Plug in your Powercenter™ to any 120v receptacle

#### Step #2

Set your X-10 (RC-4000) controller to the same letter (House code dial) ⑤ as modules and plug in your remote control to any 120V receptacle

#### Step #3

Push any button ①②③ "1-4" to turn "ON" or "OFF" your Powercenter™



Command signals are sent over existing house wiring